

Need Help?



If you're having an issue with the product or need technical support, Nilight team is always here to help and make sure your **100% satisfaction**.

► Scan QR code to contact us



service@nilight.com

nilight.com/pages/contact

► Shout Nilight out on your social media if you like it

@ nilightledlightbar @ Nilight @ nilightledlight @ NilightTeam



Front & Rear Widen Fender Flares

Content:



Instructions:

1 Take out the rivets of the original vehicle.



2 Align the wheel eye brow with the hole position, and nail the rivet.



3 Cut off the redundant rivets and complete the installation.



背面

210*148mm

正面