

420*285MM


210x285mm



Pickup Truck Rear Bumper

For 2014-2020 Toyota Tundra


(1)Contents:



X4



X6



X6



X10



X16



X8




X6




X8



X12



X4



Notes

- Read this instruction carefully before starting installation.
- Proper tools will improve the quality of installation and reduce the time required.
- Please contact us if missing parts or any damage found.

(2)Installation time: About 1 hour, 2-3 people may be needed.

210x285mm

Installation Instruction

1

Step1 Assemble the bumper.

(1)Connect the PART B1, B2 and A, with 6 of E2, E3&E5, 12 of E4.



2


Step2 Remove the factory rear bumper




210x285mm




(1)Locate and remove the wiring harness connected to the lights and the tow hitch receiver




(2)Locate and remove the single 16mm bolt attaching the rear of the tow hitch to the frame of the vehicle



(3)Locate and remove the four 16 bolts towards the front of the tow hitch.
NOTE: The removal of these bolts will allow the bumper of fall. Make sure there is sufficient support for the bumper and the hitch.



(4)Place bumper with tow hitch onto work bench and remove license plate frame




(5)Unclip plastic clips that are holding the plastic step to the top of the bumper.

(6)Remove the three 12mm bolts that attach the bumper to the tow hitch.

3

Step3
Install the new rear bumper.




(1)Attach L-Brackets to top of tow hitch, using with 4 of F1, F2&F3.



(2)Attach the new bumper, using with 4 of E1, E2&E4.



(3)Fix bumper, using with 4 of F1, F2, F4& 8 of F3.



(4)Reattach tow hitch receiver, harness and license plate lights.

Enjoy Your New Nilight Bumper!

