

# **M**LIGHT Installation Instructions

**1**

(Recommended) Apply Penetrating Lubricant to bolts and allow to sit.



## Before ▲

**2**

Along the top of the OE bumper, there will be 4 T55 Torx Screws, remove these 4 Screws with a T55 Bit



**3**

From underneath the OE Bumper, there will be 1 T55 Torx Screw on each side, remove these 2 T55 Screws with a T55 Bit



**4**

Grab both sides of your bumper and remove.



**5**

On both sides of the sway bar cover, remove 2 10mm Bolts on each side and pull the cover away from the vehicle. This will give you extra room to work.



**6**

You are ready to install the Nilight Front Bumper using the following parts:



**7**

Included Components.



**8**

Take your new Nilight bumper and slide onto frame rails.



**9**

Install the (6) 19mm hex bolts into place, leaving them loose for adjustment. Make sure the bumper is centered and then tighten all of the bolts.



**10**

Attach the included D-rings by unscrewing the clevis pin and fastening to the D-Ring mount on each side of the bumper.



**Nilight Heavy Duty Front Bumper Installation Instructions  
(87-06 Jeep Wrangler TJ/YJ)**

**Tools Required:**

T-55 Torx Bit / 10mm-19mm Sockets / 10mm-19mm Wrench



***Enjoy Your new Nilight Bumper!***

